

www.hewland.com

CONTENTS

	Page		Page
Technical Specification	4	Changing Gear Ratios	15
Recommended Torque Settings	5	Powerflow Differential	16
General Notes	6	Differential Setting	17
Differential Bearing Preload	7	TPT Differential Assembly	18
Pinion Shaft Setting	8	Illustrated Parts List	19
Pinion Bearing Preload	9	Output Flange Options	33
Crownwheel Backlash Setting	10	Gearbox Tooling	34
Sequential Barrel Setting	11	Typical Oil System Layout	35
Gearbox Assembly (Manual Gearshift)	12	Running without an oil cooler	36
Gearbox Assembly (Pneumatic Gearshift)	14	Amendments	37

ILLUSTRATIONS

	F	Page	F	⊃age
Fig.1	Differential Bearing Preload	7	Fig.12 Layshaft assembly	23
Fig.2	Pinion Shaft Setting	8	Fig.13 Pinion shaft assembly	24
Fig.3	Pinion Bearing Preload	9	Fig.14 Gear shift assembly	05
Fig.4	Crownwheel Backlash Setting	10	(Manual gear sniπ only)	25
Fig.5	Sequential Barrel Setting	11	Fig.15 Gear shift assembly (Pneumatic gear shift only)	26
Fig.6	Powerflow Differential	16	Fig.16 Input assembly	27
Fig.7	Differential Setting	17	Fig.17 Barrel/Potentiometer interfaces	28
Fig.8	TPT Differential assembly	18	Fig.18 Temperature & Pressure Sensor	00
Fig.9	Output assembly	20	fitting positions	29
			Fig.19 Output flanges	33
Fig.10	(Without integral gear shift compressor)	21	Fig.20 Gearbox tooling	34
Fig.11	Casing parts	22	Fig.21 Typical Oil System Layout	35
	(which integral gear shift compressor)	22	Fig.21 Running without an oil cooler	36

TECHNICAL SPECIFICATION

The TMT gearbox is a transaxle unit, designed for mid-engined, rear wheel drive cars. The unit is produced with six forward gears, reverse, and a powerflow differential.

The gear selection mechanism is sequential, and is available as either a pneumatically actuated semi automatic or a mechanically operated direct link, both have reverse engagement locked out. The gear selection order is Rev - Neutral - 1st 2nd 3rd 4th 5th & 6th

The drive is taken from the engine via the clutch shaft, to the layshaft, through gears to the pinion shaft, and then on to the crownwheel and differential assembly.

Gear changing is effected through non-synchronising face dogs. An extensive range of gear ratios provides a wide range of gearing requirements. The gear ratios and differential assembly can easily be changed without removing the gearbox from the vehicle.

Heat treated nickel chrome steel is used to manufacture all gears and shafts. The selector forks are also steel. Lubrication is by internal pump with distribution circuit, and the oil is retained by lipped oil seals.

In general configuration, the TMT-200 is a high tech racing transaxle unit which achieves the maximum effective use of power, in conjunction with extremely stiff integral rear suspension mountings.

1st to 6th gear ratios from 3.083:1 to 0.857:1 Final drive ratios 8/35, 9/35, 10:31 & 11/31 Clutchshafts made to customer's requirements

Weight	109 lbs (49.5Kg)
Oil type	SAE 80 or 90
Oil quantity	3.1 pints (1.75 litres) Not Including cooler or external pipe work.
Maximum torque	320 lbs.ft (430 Nm) - reduced to 210 lbs.ft (285Nm) for 8:35 final drive

RECOMMENDED FITTING TORQUES

General nut and bolt torque settings:-

RECOMMENDED TIGHTENING					
TORQ	TORQUES FOR METRIC COARSE				
SEF	RIES BOLT	S CLASS	12.9		
THREAD (Nm) (lbs.ins) (lbs.ft)					
M5 6.7 59 4.9					
M6	11.2	99	8.3		
M8	27.3	242	20.2		
M10	53.9	477	39.8		

RECOMMENDED TIGHTENING TORQUES FOR UNIFIED FINE SERIES BOLTS CLASS 12.9				
THREAD	(Nm)	(lbs.ins)	(lbs.ft)	
1/4	14.2	126	10.5	
5/16	28.4	252	21.0	
3/8	52.2	462	38.5	
7/16	82.5	731.0	60.9	

RECOMMENDED TIGHTENING TORQUES FOR UNIFIED COARSE SERIES BOLTS CLASS 12.9				
THREAD (Nm) (lbs.ins) (lbs.ft)				
1/4	12.5	110	9.2	
5/16	25.6	227	18.9	
3/8	46.0	407	33.9	

RECOMMENDED TIGHTENING TORQUES FOR METRIC COARSE SERIES K-NUTS				
	FITTI	NG TO EN16T S	STUDS	
ITIKEAD	(Nm)	(lbs.ins)	(lbs.ft)	
M5	8.4	75	6.2	
M6	12.7	112	9.3	
M8	27.0	239	19.9	
M10 x 1.50	40.0	354	29.5	
M10 x 1.25	50.0	443	36.9	

Specific nut and bolt torque settings:-

(Where Specific nut and bolt details are a similar size to General nut and bolt details, the tightening torques listed in this section must be adhered to for these components.)

Barrel Bolt tightening torque = 35 lbs.ft (48 Nm)

Pinion shaft nut tightening torque = 120 lbs.ft (163 Nm)

Crownwheel bolt tightening torque = 75 lbs.ft (100 Nm) (Lockwire must also be applied to these bolts.)

GENERAL NOTES

- a) Read these instructions carefully and with reference to the illustrations.
- b) Before dismantling the gearbox, see that a clean tray is available, in which to place the parts.
- c) Thoroughly clean and inspect all parts before reassembly. Discard any worn or damaged components and replace with new ones.
- d) Use only genuine Hewland parts as replacements. These are manufactured in our workshops to the fine tolerances necessary and are rigorously inspected.
- e) Always ensure that locknuts, and oil seals are in good condition when reassembling.
- f) All studs and screws must be Loctited or wirelocked in position, unless stated otherwise
- g) Bearing Replacement :-

Bearings can only be removed or renewed if the casings have been warmed in an oven, or with a blowlamp. In the latter case, keep the blowlamp moving while heating the casing.

NB. Do not overheat. Test with a spot of water which will bounce off at the correct temperature. Once a casing is heated, all bearings should be pressed into their respective seatings without delay, thus eliminating the need to reheat. At the correct temperature, fitting the bearings should present no difficulty.

During cooling, or when the casings have cooled, it is advisable to once more lightly press the bearings to ensure that they are correctly seated.

h) Oil:

Fill the gearbox through the oil filler hole on top of the maincase. The oil will find it's own level within the gearbox. NB. Too much oil will not directly cause any harm, but is undesirable as it will induce power loss and overheating of the internals.

DIFFERENTIAL BEARING PRELOAD

Using the original shims (40) as a guide, fit the outer races of bearings (37) to the maincase and side cover. Fit the inner races of the bearings to the differential case. Offer up the differential assembly to the maincase and fit the sideplate. Adjust shims (40) as necessary to achieve 0.012"/0.015" of preload, giving 4/6 lb ft (5.4/8.1 Nm) torque to turn. (With bearings oiled.)

Refer to page 19 for part references.

The table below is to inform you of which sideplate spacers should be used with which crownwheel when mounted on a TPT differential. The reason that there are two sets of spacers, is that the crownwheels have different mounting distances.

PART NUMBER	RATIO	MOUNTING DISTANCE	ITEM (41)	ITEM (68)
NLT-221-CW	9/35	2.200"	FGC-205-2A	NMT-205-2A
NMT-221-BW	10/31	2.316"	FGC-206-2A	NMT-205-2
NMT-221-AW	11/31	2.316"	FGC-206-2A	NMT-205-2

Refer to page 19 for part references.



FIGURE 1

PINION HEIGHT SETTINGS

Requires special tool No.SK-1470-A

Press the inner race of the pinion head bearing (67) onto the pinion shaft (69). Fit the bearing outer race and nominal shim pack (66) into the maincase (102). Assemble the pinion shaft into the maincase, then fit the tail bearing outer race (14) to the bearing carrier (105), and secure it to the maincase. Tighten the pinion shaft nut (110) onto the pinion shaft until the shaft requires 20-25 lbs.in (2.2-2.8Nm) to turn it in it's bearings.

Fit tool SK-1470-A into the maincase diff bearing bore, and use feeler gauges to measure the gap between the tool and the pinion shaft front face. This clearance should comply with the dimension indicated on the crownwheel & pinion label (also etched on the head of the pinion shaft), and can be adjusted by reducing the peelable shimpack (66) behind the pinion head bearing outer race. Refer to page 19 for part references.

Alternatively, the pinion mounting distance can be measured with a height gauge, and set to the dimension indicated on the pinion shaft label (also etched on the head of the pinion shaft).



NB. It is not correct practice to replace a pinion shaft without checking the setting distance, <u>even if the old and</u> <u>new shafts have the same recorded setting distance.</u>

It is also good practice to renew the pinion head bearing if the pinion shaft is being replaced.

PINION BEARING PRELOAD

Having obtained the correct pinion setting, remove the bearing carrier (105). Add the reverse gear spacer (71), reverse gear inner track (109), reverse clutch ring (31), 3 off hubs (2) and spacer (108) to the pinion shaft. Replace the bearing carrier (105), bearing inner race (24) and pinion nut (110). Tighten the pinion shaft nut until the shaft requires 20-25 lbs.in (2.2-2.8Nm) to turn it in it's bearings.

If necessary adjust the preload across the bearings by grinding the pinion shaft spacer (71) on it's pinion bearing face to reproduce the pinion shaft setting figure (see previous page) It is essential that if any component on the mainshaft is renewed, then the bearing preload must be checked and adjusted as required.

Refer to page 19 for part references.

NB. It is essential that the pinion bearing preload is checked and adjusted if any of the pinion shaft components are replaced, with the exception of the locknut and locking ring. Fitting a longer reverse gear spacer (71) will decrease the pinion bearing preload, whereas shortening the reverse gear spacer (71) will increase the pinion bearing preload.



FIGURE 3

CROWNWHEEL & PINION BACKLASH SETTING

Requires special tool No. SK-1913

With the pinion shaft, differential assembly, and sideplate fitted, and the correct diff bearing shims ascertained, the actual backlash can be measured by means of a dial test indicator against the relevant crownwheel & pinion ratio mark etched in the face of tool SK-1913. Be sure to take at least 6 backlash readings, turning the crownwheel 30-45 degrees between each reading (this is to ensure that any variation due to manufacturing tolerances are taken into account). The backlash variation from manufacture will be logged on the gear data card supplied with each crownwheel & pinion set.

The correct minimum backlash figure should be 0.005" (0.13mm) taken at the tightest point of gear mesh. If the measured backlash is incorrect, rectify it by removing some shims (40) from behind one diff bearing, and inserting the equivalent amount of shim behind the other, thus moving the diff across in the maincase.

NB. Generally 0.001" of crownwheel axial adjustment equates to 0.0008" modification in gear set backlash.

Do not add or discard any shims, as to do so will affect the differential bearing preload.

NB. Dummy bearings can be used to ease the shim change during the setting procedures. However, before fitting the actual differential bearings, it is important to compare their width with that of the dummy bearings and compensate the shim thicknesses for any difference.



FIGURE 4

SEQUENTIAL BARREL SETTING

Requires special tool No. SK-2311

Build up the assembly into the maincase, and fit the fork setting fixture as shown, making sure that the barrel is in the neutral position before securing the face plate of the fixture.

Measure and record the dog face clearance for 5th and 6th gears. Their position in the maincase, (furthest away from the datum face), means any dog clearance errors due to tolerance build up, will be at their worst. Therefore it is acceptable to adjust the barrel position according to these readings. Any difference in the dog face clearance between these gears must be averaged out by changing the barrel setting spacer (32). Spacers of various thicknesses are available, as shown in Fig.6.

In order to change this spacer, the face plate of the fixture, the mainshaft locknut (110), selector rail (114), selector forks (22) and the barrel bolt (118) must be removed. (Please note for clarity the selector rail (114) and selector forks (22) have not been shown in Fig.6).

Removal and replacement of the barrel bolt (118) is made easier if a suitable tool is located into the radial hole in the barrel (117) and the reverse blocker hole in the maincase above it.

NB. It is not possible (or necessary) to individually adjust each fork.



GEARBOX ASSEMBLY (Manual Gear Shift)

- a) It is assumed that all bearings, oil seals, studs, oil jets, and dowels are already fitted into their casings.
- b) Slide the reverse idler top hat bush (48) into place in the maincase (102), then push it in as far as it will go. Slide the second reverse idler top hat bush (34) into place, then pull it towards the rear of the maincase. Press the bearing (52) into the reverse idler gear (33), slide the sleeve (49) into the bearing, and position the gear between the bushes. Push the reverse idler top hat bush (34) towards the front of the maincase, fit the screw (87), and lockwire.
- c) Press the dowel (35) into the maincase, and secure the detent arm (82), trunion (51), and spring (83) into the maincase using screw (59) and washer (53).
- d) Position the pawl (91) in the slot in the selector rack (153), and press pin (30) into place ensuring that it does not protrude outside the rack outer diameter, and moves freely. Slide the washers (50), spring (155), and sleeve (156) onto the rack and secure them with circlip (16). This spring has a limited effective life, therefore periodic replacement is recommended. It is also advisable never to re-use the circlip (16).
- e) Fit the quad ring seal (154) carefully into the seal carrier (152), then assemble it onto the maincase using screws (90) ensuring o-ring (78) is fitted. Fit the spring carrier (151), into the maincase, oil the rack liberally and slide it in, ensure that it travels back and forth without any stiction. Fit the anti-rotation pin (93) and washer (128) into the maincase.
- f) Put the fork setting spacer (32) onto the barrel (117) and whilst holding the detent arm against its spring using a pair pliers feed the barrel into the maincase and secure with the barrel bolt (118). It may be necessary to lift the pawl up so as to let the barrel pass underneath it.
- g) Slide the plunger (92), spring (1) and washer (36) into the rack and secure with circlip (15), then fit rack cover (150) and o-ring (78), using screws (90). NB. If the gearbox has not yet been fork set, then delay this step, as it easier to push the pawl up if it has not yet been fitted with its return spring.
- h) Assemble the bell crank (162), bearings (160), spacer (161), washers (158) and shim washer (159) to the maincase and secure with screw (157) and nut (163). Ensure by adjusting the shim washer thickness that the selector operates smoothly in both directions, and self returns to its normal position. Fit the bearing (28) onto the clutchshaft (18) and secure using circlip (26). Fit oilseal (44) into slave adaptor (116), and slide the slave adaptor over the clutchshaft to enable fitting of bearing circlip (27). Offer up clutchshaft assembly to the maincase with o-ring (29) in place and secure with screws (90).

GEARBOX ASSEMBLY (Manual Gear Shift)

- j) Fit the bearing (28) onto the clutchshaft (18) and secure using circlip (26). Fit oilseal (44) into slave adaptor (116), and slide the slave adaptor over the clutchshaft to enable fitting of bearing circlip (27). Offer up clutchshaft assembly to the maincase with o-ring (29) in place and secure with screws (90).
- k) The gear cluster can now be loaded into the maincase, (this is assuming that the pinion, and pinion bearing preload have been set as previously described). With the pinion shaft (69) complete with the pinion head bearing (67) inner race held in position in the maincase the pinion gears, spacers, hubs, bearings and clutchrings can be slide onto it. It is necessary to fit the relevant selector forks in conjunction with their clutchring, locating the selector fork pin into the barrel track, once all four forks are correctly located with their clutchring, and the barrel, then the selector rail (114) can be slid through all of the forks and into the maincase. The layshaft, input gears, and spacers can now also be assembled into the maincase. (See figure 12 for details of both layshaft designs). NB The pinion gears may need rotating in order to allow the input gears to pass and mesh properly.
- The bearing carrier (105) can now be fitted with the barrel oilseal (64), barrel bearing (8), pinion shaft bearing outer (14), layshaft bearing outer race (11), and secured onto the maincase, ensuring that the o-ring cord (125) has been correctly fitted into its groove.
- m) The pinion shaft bearing inner race (24), and locknut (110) can now be fitted and tightened to the recommended torque, the locknut locking ring (72) and retaining circlip (43) can now be applied.
- n) The oil pump gears (112), (120), and rear cover (123) can now be fitted ensuring that the o-ring (76) has been correctly located in its groove.
- p) Fit the output shaft oilseal (39), bearing (38), and output flange (107) in the maincase, securing it with circlip (23). Fit similar parts into the sideplate (106). Assuming that the differential bearing preload and the crownwheel and pinion backlash have been set as previously described, then the differential can be fitted into the maincase, and the sideplate (106) secured into position ensuring that the o-ring (81) is fitted.
- r) Fit all ancillary parts, oil filters, pinion oil spray, breather and oil fittings.
- s) Assemble the neutral/reverse blocker and fit it into the maincase above the barrel. NB When installing the gearbox into the car, the blocker release cable length should be adjusted so that the blocker plunger is held just clear of the barrel when a forward gear is selected.

Refer to page 19 for part references.

GEARBOX ASSEMBLY (Pneumatic Gear Shift)

- a) All assembly details are as for the manual gear shift with the exception of the rack.
- b) Position the pawl (91) in the slot in the selector rack (20), and press pin (30) into place ensuring that it does not protrude outside the rack outer diameter. Slide the washer (50), spring (95), and sleeve (21) onto the rack and secure them with circlip (16). This spring has a finite life and will weaken with use. A new spring has a free height of 2.000". It is also advisable never to re-use the circlip (16). Slide the plunger (92), spring (1) and washer (36) into the rack and secure with circlip (15). Slide rack assembly into the rack bore of the maincase.
- c) Carefully mount the glide rings (13) and hydraulic seals (80) onto both of the pistons (19), fit a spring (96) into both piston housings (119), and slide the pistons in after them, it is essential that the pistons are fitted into the housings correctly with the hydraulic seals positioned furthest away from the selector barrel.
- d) The piston housings (119) can now be secured using screws (90) to the maincase ensuring that oring (78) is fitted to both.

Refer to page 19 for part references.

NB. If it is necessary to remove the barrel from the maincase without removing the rack, then this can be achieved by removing the piston housing, and piston from the right hand end of the rack, so exposing the rack end. The 5mm set screw located in the rack can now be removed, and a suitable tool can then be pushed up the Ø5mm hole that runs up the centre of the rack. This tool can then lift the pawl against its return spring, so allowing the barrel to pass underneath it and out of the maincase, once the barrel bolt has been removed. The 5mm set screw must be re-fitted using a suitable thread sealant to ensure the gearbox oil does not leak up through the rack.

CHANGING GEAR RATIOS

- a) With a drip tray placed beneath the gearbox, remove the magnetic drain plug (54) and drain the oil.
- b) Remove the nuts (73) and washers (36) securing the rear cover (123), oil pump gears (112), (120) and the pinion shaft bearing locking ring retaining circlip (43).
- c) Remove the retaining ring (72), the locknut (110) and the pinion bearing inner race (24).
- Remove the nuts (73) and washers (36) securing the bearing housing, and slide it off of the maincase.
 It may be necessary to lightly tap the bearing carrier using a soft mallet, never use a screwdriver to lever between the joint faces, as this may damage the faces and impair the seal efficiency when reassembled.
- e) Remove the selector rail from the maincase sliding it out of the selector forks, and systematically remove the ratios, spacers, hubs, bearings, clutchrings and selector forks, from both the pinion shaft and layshaft, as necessary. The layshaft itself can now be removed from the maincase if so desired.
- f) Replace the gears with the required ratios. Gears are supplied in matched pairs, one for the mainshaft and one for the layshaft. Each gear is marked with two sets of numbers. The first of these indicates the number of teeth on the layshaft gear, while the second signifies the number of teeth on the mainshaft gear which mates with it. (e.g. 16/32) Both gears of each pair are marked in an identical manner. It is essential that gears are correctly paired to these numbers. On all first gears, and some second gears, the gear teeth are machined integral with the layshaft. In such cases, therefore, if a first, or second, gear ratio change is required, the layshaft itself must be changed. If the integral first/second layshaft is fitted, then the third gear ratio on the layshaft is a hubbed gear, if the first only gear is integral on the layshaft, then second and third gear ratios are standard gears and spacers (5) and (180) are required. Refer to figure 12 for details.
- g) Whilst changing ratios it is advisable, as a matter of course, to wash and inspect all components which are to be used again before refitting. Check for wear and cracks, particularly to the clutch rings. Also examine the selector forks for heavy or uneven wear.
- h) Reassembly is the reverse of disassembly. Take care, when refitting the gear cluster into the maincase, to ensure location of the layshaft into it's bearing.

Refer to page 19 for part references.

POWERFLOW DIFFERENTIAL

This powerflow differential unit is designed with versatility as it's major asset. Many factors will contribute to the settings required. A car with good traction and low power, may require a completely different arrangement to that of a car with poor traction and high power. There are 10 friction plates within the unit (4 splined to the diff casing, and 6 splined to the side bevel gears). Slip limiting is dependent on the friction resistance between these plates, and is affected by clamping the plates together. Four factors contribute to the total friction torque between the plates :-

1) The side bevel gears thrust apart to clamp the plates as they transmit the driving power. This is a feature of the gear geometry, and is not adjustable.

2) The side ring gear ramp angles have an effect on how much of the transmitted torque is converted into sideways (clamping) force onto the plates. For example, on the drive side of the ring gear, 45 degrees transmits less sideways force than 30 degrees. Likewise on the coast side of the ring gear, an 80 degree angle will transmit little or no clamping force onto the plates, whereas a 45 degree angle will transmit a much greater force. The side rings gear are available with many different drive/coast ramp angle combinations.

3) The second adjustable factor is how tightly the plate stack is compressed on assembly (known as static preload). The preload torque is measured between the side bevel gears, by holding one side bevel gear stationary, and measuring the torque required to turn the other. NB. Figure 6 shows a belleville spring fitted to the plate stack, that can be used to maintain static preload during the "running in" period.
4) The final adjustment is simply to re-order the plate stack so as to change the number of relatively rotating faces. The diagram shows the stack setup with the maximum 12 working faces. Standard stack may be shuffled to give as few as 2 working faces.



Percentage Rating	Ramp Angle	No. of Friction Surfaces
4	85	2
4	80	2
7	85	4
7	60	2
ω	80	4
1	85	9
11	45	2
13	80	9
14	85	8
15	60	4
17	80	8
17	30	2
18	85	10
21	85	12
21	80	10
22	60	9
22	45	4
25	80	12
30	60	8
33	45	9
33	30	4
37	60	10
43	45	ω
45	60	12
50	30	9
54	45	10
65	45	12
67	30	8
83	30	10
100	30	12

FIGURE 7

DIFFERENTIAL SETTINGS

TPT DIFFERENTIAL ASSEMBLY

PLATE
ED
TING

PART 302 MUST BE FITTED USING LOCTITE RETAINER AND WIRELOCKED

		CARRIER	
SPRING	CS-1401	PHR-213-3	PHR-213-3B
SPR-038	0 LBSFT	50 LBSFT	95 LBSFT
SPR-065	0 LBSFT	65 LBSFT	80 LBSFT

Various Bellville springs (311) and Carriers (310) are available. The preload value given is the initial value that will be given without any additional shims, shims can be added to the carrier to give higher preloads



FIGURE 8

ILLUSTRATED PARTS LIST





CASING PARTS (WITH INTEGRAL GEAR SHIFT COMPRESSOR)



LAYSHAFT ASSEMBLY





FIGURE 13





GEAR SHIFT ASSEMBLY (PNEUMATIC GEAR SHIFT ONLY)



BARREL/POTENTIOMETER INTERFACES

MANUAL SHIFT





TEMPERATURE & PRESSURE SENSOR POSITIONS



PRESSURE SENSOR POSITION (IF SENSOR IS NOT REQUIRED THEN A BLANKING PLUG MUST BE FIITED)

TEMPERATURE SENSOR POSITION (IF SENSOR IS NOT REQUIRED THEN A BLANKING PLUG MUST BE FIITED)

FIGURE 18

	Item No	Part Number	Description	Qty
	1	102-260-9	COMPRESSION SPRING	1
	2	104-226-1	НИВ	3
	3	104-226-2	NEEDLE ROLLER BEARING	6
	4	TE-**:**/**:**	PINION SHAFT GEARS	1
Ж	5	104-234-4	LAYSHAFT SPACER	1
	6	104-RATIO-STD	104 GEAR ASSEMBLY	4
	7	105-234-8	DISC SPRING	1
	8	105-260-6	NEEDLE ROLLER BEARING	1
	9	400-021-4490-41	DOWTY WASHER	2
	10	BEA-001	ROLLER BEARING	1
	11	BEA-093	ROLLER BEARING	1
	12	BEA-141	BALL BEARING	1
	13	BEA-360	WEAR RING	2
	14	BEA-382	TAPER ROLLER OUTER	1
	15	CIR-082	CIRCLIP	1
	16	CIR-084	CIRCLIP	1
	17	CIR-189	CIRCLIP	1
	18	TMT-239-#	CLUTCH SHAFT	1
	19	CPK-260-2	PISTON	2
	20	CPK-260-3	SELECTOR RACK	1
	21	CPK-260-5	SELECTOR RACK WASHER	1
	22	CST-250-C	SELECTOR FORK ASSY	3
	23	DG-219-1A	CIRCLIP	2
	24	DG-222-1C	TAPER ROLLER BEARING	1
	25	DG-232-A4D	CLUTCH RING	3
	26	DGB-239-0	EXTERNAL CIRCLIP	1
	27	DGB-244-10	INTERNAL CIRCLIP	1
	28	DGB-244-12	BALL BEARING	1
	29	DGB-244-14	O-RING	1
	30	DOW-063	DOWEL	1
	31	DTR-231-1	REVERSE CLUTCH RING	1
	32	DTR-260-7	BARREL SPACER	1
	33	EGT-237-1	REVERSE IDLER	1
	34	EGT-237-2	REVERSE IDLER SPIGOT	1
	35	F3A-202-9A	DOWEL	1
	36	F3D-236-1	WASHER	30
	37	FGC-205-1	TAPER ROLLER BEARING	2

Item No	Part Number	Description	Qty	
38	FGC-205-3	BALL BEARING	2	
39	FGC-205-4	LIP SEAL	2	
40	FGC-206-1#	SHIM	A/R	
41	FGC-206-2A	SIDEPLATE SPACER	1	
42	FT-202-8	SOCKET SET SCREW	4	
43	FT-219-1A	CIRCLIP	1	
44	FT-244-11	OIL SEAL	1	
45	FTR-202-2	BEARING RETAINING PLATE	1	
46	FTR-210-35	PLUNGER	1	
47	FTR-210-36	PLUG	1	
48	FTR-237-1	REVERSE IDLER SPIGOT	1	++
49	FTR-237-2	SLEEVE	1	
50	FTR-260-4	SELECTOR RACK WASHER	1	
51	FTR-260-8	SPRING TRUNION	1	
52	HC-237-2	NEEDLE ROLLER BEARING	1	
53	HP-M-7039	DRUM WASHER	1	
54	HP-M-9004	MAGNETIC DRAIN PLUG	1	
55	HP-M-9037	BANJO JOINT	1	
56	HP-M-9038	SEALING WASHER	2	
57	HP-M-9039	BANJO BOLT	1	
58	HP-M-9042	DOWTY WASHER	1	
59	HP-M-9054	SOCKET CAP SCREW	1	
60	HP-N-9006	SOCKET CAP SCREW	2	
61	HYD-016	ADAPTOR	2	
62	LD-201-2	STUD	6	
63	LD-201-5	DOWEL	2	
64	LIP-041	OIL SEAL	1	
65	NCH-266	OIL FILTER	1	
66	NLT-223-2	PINION HEAD BEARING SHIM	1	
67	NLT-223-A	PINION HEAD BEARING HOUSING	1	
68	NMT-205-2	SIDEPLATE SPACER	1	
69	NMT-221-#P	PINION SHAFT	1	
70	NMT-221-#W	CROWNWHEEL	1	
71	NMT-229	PINION SHAFT SPACER	1	
72	NMT-230-1	LOCKING RING	1	
73	NUT-004	KAYNUT	29	
74	ORI-001	O-RING	1	
				•

© Copyright Hewland Engineering Limited 2008

++ Gearboxes marked up to and including 029, part number 48 is SK-2363

	Item No	Part Number	Description	Qty
	75	ORI-002	O-RING	2
	76	ORI-232	O-RING	1
	77	ORI-072	O-RING	2
	78	ORI-118	O-RING	2
	79	ORI-170	O-RING	1
	80	ORI-213	VL SEAL	2
	81	ORI-214	O-RING	1
	82	PCT-260-2	DRUM STOPPER	1
	83	PCT-260-3	COIL SPRING	1
	84	PLU-030	PLUG	1
	85	SCR-175	SOCKET CAP SCREW	2
	86	SCR-042	SOCKET CAP SCREW	5
	87	SCR-117	SOCKET CAP SCREW	1
	88	SCR-121	SOCKET SET SCREW	2
	*89	SCR-166	SOCKET SET SCREW (Version 1 to 16 maincases)	1
	*89	PLU-129	SEALING SCREW (Version 17 maincases & onwards)	1
	90	SGT-244-13	SOCKET CAP SCREW	10
	91	SPH1077-M3	PAWL	1
	92	SPH1078-M3	PLUNGER	1
	93	SCR-349	ANTI-ROTATION PIN	1
	94	SPR-058	COMPRESSION SPRING	1
	95	SPR-127	COMPRESSION SPRING	1
	96	SPR-131	SPRING	2
	97	SPR-142	COIL SPRING	1
	98	STU-036	STUD	8
\ast	99	STU-074	STUD	13
	100	TE-**:**-INT	LAYSHAFT VARIANTS	1
	101	TE-234-2	BEARING INNER TRACK	1
	102	TMT-301	MAINCASE	1
	103	TMT-201-1	RATIO SPRAY RAIL	1
	104	TMT-201-2	SPRAY RAIL ASSEMBLY	1
	105	TMT-302	BEARING CARRIER	1
	106	TMT-205	SIDEPLATE	1
	107	OUTPUT FLANGE	OUTPUT FLANGE	2
	108	TMT-221-1	SPACER	1
	109	TMT-228	REVERSE INNER TRACK	1
	110	TMT-230	MAINSHAFT NUT	1
	111	TMT-231	REVERSE PINION GEAR	1

Item No	Part Number	Description	Qty
112	TMT-234-1	OIL PUMP DRIVE	1
113	TMT-239-	CLUTCH SHAFT	1
114	TMT-246	SELECTOR RAIL	1
115	TMT-249-A	REVERSE SELECTOR FORK	1
116	TMT-258-1	SLAVE ADAPTOR CP3859	1
116	TMT-258-2	SLAVE ADAPTOR CP3759-3959	1
117	TMT-260-M	MANUAL SELECTOR BARREL	1
117	TMT-260-S	SEMI-AUTO SELECTOR BARREL	1
118	TMT-260-1	BARREL BOLT	1
119	TMT-260-4	PISTON HOUSING	2
120	TMT-265-1	OIL PUMP ROTORS	1
121	TMT-266	OIL FILTER	1
122	TMT-266-1	OIL FILTER COVER	1
123	TMT-308	REAR COVER	1
124	TPT-212	TPT DIFF ASSEMBLY	1
125	VG-201-9	O-RING	1
126	VG-221-1	CROWNWHEEL BOLT 7/16 UNF	8
127	VG-222-1A	TAPER ROLLER BEARING EX LR	1
128	WSH-028	WASHER	1
129	MLI-223-1	CLAMP PLATE	1
130	WSH-078	DOWTY WASHER	1
150	TMT-260-5	RACK END COVER	1
151	TMT-260-6	RACK SPACER	1
152	TMT-260-7	RACK SEAL HOUSING	1
153	FTR-260-3	RACK	1
154	ORI-227	QUAD RING	1
155	SPR-057	SPRING	1
156	FTR-260-5	TRAVEL STOP SPACER	1
157	HP-M-9008	SOCKET CAP SCREW	1
158	LD-202-9	WASHER	4
159	WSH-067	SHIM WASHER	1
160	BEA-162	BEARING	2
161	FTR-260-2	SPACER TUBE	1
162	FTR-260-7	BELL CRANK	1
163	NUT-005	KAYNUT	1
164	TE-201-4	BLANKING PLATE	1
165	HP-M-9062	BLANKING PLATE SCREWS	2

	Item No	Part Number	Description	Qty
\ast	166	104-234-4	SPACER	1
	170	ELC-024	MANUAL POTENTIOMETER	1
	171	TMT-260-2	POT SPIGOT	1
	172	HP-M-9062	SCREWS	3
	173	ZH147-01	OLDHAM COUPLING	1
	174	AVM-002	ANTI-VIBRATION MOUNTS	3
	175	TMT-202-1	MOUNTING PLATE	1
	176	TBA	SEMI-AUTO POTENTIOMETER	1
	180	ELC-036	TEMPERATURE SENSOR	1
	181	ELC-035	PRESSURE SENSOR	1
	182	WSH-007	DOWTY WASHER	1
	183	400-222-4490-41	DOWTY WASHER	1
	184	BEA-263	SPLIT BEARING	1
	201	400-021-4490-41	DOWTY WASHER	1
	202	BEA-374	BALL BEARING	1
	203	BEA-375	BALL BEARING	3
	204	CIR-021	CIRCLIP	1
	205	HYD-016	ADAPTOR	1
	206	HYD-059	ADAPTOR	1
	207	LIP-041	OIL SEAL	1
	208	ORI-042	O-RING	4
	209	ORI-097	O-RING	4
	210	ORI-213	VL SEAL	2
	211	PNU-005	FLAPPER VALVE	2
	212	PNU-006	FLAPPER VALVE	2
	213	PNU-007	BACKING PLATE	2
	214	PNU-010	CYLINDER HEAD	1
	215	PNU-011	VALVE CARRIER	2
	216	PNU-012	CRANK SHAFT	1
	217	PNU-013	PISTON	1
	218	PNU-019	CYLINDER HEAD LH	1
	219	SCR-155	SOCKET CAP SCREW	4
	220	SCR-317	SOCKET BUTTON HD SCREW	4
	221	SCR-320	ANTI ROTATION PIN	2
	222	TMT-308-A	REAR COVER DRESSED	1
	223	WSH-090	DOWTY WASHER	1

Item No	Part Number	Description	Qty
224	PLU-048	BLANKING PLUG	1

 \star THESE PARTS, PLUS AN ADDITIONAL (6) , ARE REQUIRED IF THE ALTERNATIVE 1ST GEAR ONLY INTEGRAL LAYSHAFT IS REQUIRED.



GEARBOX TOOLING



TMT TYPICAL OIL SYSTEM LAYOUT



FIGURE 21



Amendments

Date Modification

- 16/01/2009 1st Issue
- 15/10/2009 Item numbers 129 and 086 updated, amendments page added
- 20/01/2010 output flanges page added
- 23/06/2010 Seal tools added
- 13/10/2010 Part 224 added to page 26 & 32
- 25/10/2010 Page 7 item 71 changed to pinion shaft spacer for clarity, TMT-201 and TMT-202 changed to TMT-301 and TMT-302 respectively
- 01/11/2010 Running without oil cooler page added
- 14/09/2011 Page 34 Tooling updated SK-2212 and SK-2213 replaced by SK-2239 and SK-2240
- 02/12/2011 Page 4 Torque rating corrected for 8:35 f/drive ratio
- 05/12/2011 Page 31 Item 89 updated for new version of maincase